

NEMAN RECESSED

HOLECTRON

Installation guide



- For indoor use only.
- Product installation must be carried out by a qualified professional.
- Before installing make sure, that electrical power is turned **OFF**.
- Before installing make sure, that the fixing area can bear the total weight of the luminaire.
- Pay attention to polarity when connecting (installing) the product.
- Do not operate if the luminaire has been damaged.
- To protect the surface from dirt and fingerprints, we recommend the use of protective gloves during installation.
- Product warranty does not cover any damage caused by faulty installation and/or misuse.
- For further information, please contact the manufacturer.

Luminaire	Cutting hole size, mm (ft)	Luminaire	Cutting hole size, mm (ft)
L-560	568 x 38 mm (1.86' x 1.49")	L-1960	1968 x 38 mm (6.46' x 1.49")
L-840	848 x 38 mm (2.78' x 1.49")	L-2240	2248 x 38 mm (7.38' x 1.49")
L-1120	1128 x 38 mm (3.7' x 1.49")	L-2520	2528 x 38 mm (8.29' x 1.49")
L-1400	1408 x 38 mm (4.62' x 1.49")	L-2800	2808 x 38 mm (9.21' x 1.49")
L-1680	1688 x 38 mm (5.54' x 1.49")	L-3080	3088 x 38 mm (10.13' x 1.49")

Min ceiling thickness 10 mm (0.39 in) Max ceiling thickness 40 mm (1.57 in)

1

CONNECT

2

WIRING

3

4

5

6

7

INSTALLATION COMPLETED

8